

Type 8436 DataPower Gateway appliances

Version 1.0



Quick Start Guide

This guide summarizes the installation process and reviews the most common signs-of-health for type 8436 appliances.

National Language Version: To obtain the Quick Start Guide in other languages, print the language-specific PDF from the resource kit.

Product overview

IBM® DataPower® Gateway appliances are easy-to-deploy network devices that help simplify, accelerate, and secure your XML and web services. For complete installation instructions, see the *Installation and User's Guide*.

1 Step 1: Getting started



Gather the following information.

- The IP address for the Ethernet interface for management access.
- The IP addresses for Ethernet interfaces for service access.
- The IP address of the default gateways (routers) that supports the subnets for the Ethernet interfaces.
- The IP address and port for the web management service (required to accept the license agreement).
- The IP address and port for the SSH service.
- Optional: The IP address and port for Telnet service.

2 Step 2: Physically installing



To know where to connect each type of cable, review the graphics in the *Installation and User's Guide* for the front and back panels.

1. Carefully unpack the appliance, and locate all supplied power cords, the serial cables, and the rail kit.
2. Identify the rack location for installation, and ensure that there is sufficient space for ventilation and maintenance.
3. Secure the mounting rails.
4. Install the appliance on the rails, and slide the appliance into place.
5. Use network cables to connect at least one management Ethernet port to a switch that is on your network. Ethernet cables are not supplied.
6. Use the supplied power cords to connect both power supplies to power outlets.
7. Connect a supplied serial cable from a PC that is running terminal emulation software, to the console connector. Ensure that the connection is 115200 baud 8N1 (8 bits per character, no parity, 1 stop-bit), and no flow control.
8. Press the power button.

The power LED is illuminated. The terminal displays DPOS... From the ASCII terminal or PC running the emulation software, the Login prompt is visible.

3 Step 3: Configuring the appliance for access



1. At the Login prompt, enter admin.
2. At the Password prompt, enter admin. The script prompts you later to change this password.
3. Review and accept operational modes for the appliance.
4. At the Please enter new password prompt, enter a new password.
5. At the Please re-enter new password to confirm prompt, enter the new password again.
6. At the Do you want to run the Installation Wizard prompt, enter y to start the installation wizard.
7. Follow the prompts to complete the base configuration.

4 Step 4: Accepting the license agreement



You must accept the license agreement through the WebGUI. If an error occurred during the base configuration, retaining the serial connection is helpful until access to the WebGUI is complete.

1. From a network-connected PC, open a web browser.
2. In the **Address Bar**, enter the IP address and port of the web management interface. For an example that assumes the IP address of 10.10.13.35 and a listening port of 9090, you would enter `https://10.10.13.35:9090` as the address. Use the secure HTTP protocol (`https`, not `http`).
3. At the WebGUI login screen, provide the credentials for the admin account.
 - a. In the **User** field, enter `admin`.
 - b. In the **Password** field, enter the new password for the admin account.
4. Click **Login**.
5. Select the **I accept the terms of the license agreement** check box.
6. Accept the license agreement.

After you accept the license agreement, the appliance reloads the firmware. When the appliance restarts in a few minutes, you can log in again.

5 Step 5: Confirming operational states



Confirm the following operational states.

- The power LED is illuminated.
- The fault LED is not illuminated.

If these states do not match your appliance, see the *Installation and User's Guide* for troubleshooting information.

More information



If you have concerns, contact IBM Support. Go to <http://ibm.com/support/entry/portal/support>

Third edition (October 2015)

IBM DataPower Gateway Licensed Materials - Property of IBM. © Copyright IBM Corp. 2015. US Government Users Restricted Rights - Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

IBM, the IBM logo, and `ibm.com`® are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Copyright and trademark information website (<http://www.ibm.com/legal/copytrade.shtml>).

Part Number: 97Y1319

EC L68777



Printed in Mexico